



Use in Freezing Conditions

Ultra-Sensitive Formula

1 U.S. Gallon (3.786 liters)

BENEFITS

Big Blu Sub Zero is the original low temperature micro leak detector known for its long lasting bubbles. This one of a kind elastic liquid easily clings to all surfaces. It is the only bubble leak detector capable of identifying leaks down to 0.65oz/yr. It is safe to use on all gases including oxygen. Freeze protected to -30°F, non-corrosive, biodegradable, and NSF approved for use around food. Please see directions and visit our website for more information.



Manufactured by:



a Family Company Since 1987.

DIRECTIONS

Turn off or Disconnect all power from system.

Coat all surfaces with a flat liquid free of foam.

Tip: Focus on threaded connections, joints, and valves. Read our "Leak Detection Manual" online for more information.

Bubbles will form instantly for most leaks. Wait 5-30 minutes. Micro leaks will develop and appear as white foam cocoons or tiny bubble clusters. Place unit back into operation and check for vibration leaks.

Wipe or rinse off surfaces if water is available.

All done!



Part#RT150G

OUR STORY

Designed by a service tech for a service tech

"As a service technician for over 17 years, I combined my HVAC/R expertise with my chemistry background to develop a family of products that every technician will want on their truck. Refrigeration Technologies is the most trusted name for innovative products in the industry."

Thank you for purchasing!

John Pastorello
Founder & CEO



0 17857 15128 1

Big Blu Sub Zero

SIGNAL WORD: None Required
PICTOGRAM: None Required

HAZARD STATEMENT:

This product is not classified as hazardous according to GHS.

PRECAUTIONARY STATEMENTS:

Avoid all unnecessary exposure by wearing gloves, goggles and use in well ventilated areas.

KEEP OUT OF REACH OF CHILDREN

FIRST AID: Inhalation:

Assure fresh air breathing. Allow the victim to rest.

Skin contact:

Remove affected clothing and wash all exposed skin area with mild soap and water.

Eye contact:

Rinse immediately with plenty of water. Obtain medical attention if pain, blinking or redness persist.

Ingestion:

Rinse mouth. Do NOT induce vomiting. Obtain emergency medical attention.

DISPOSAL:

Dispose of in accordance with your local regulations. Recycle Container.

Manufactured by:

Refrigeration Technologies,
1111 N. Armando St, Anaheim, CA, 92806 USA.
Ph: 714-238-9207.

Fax: 714-238-9234. Web: www.refrig.com
24 Hour Emergency Phone Chem-Tel: 1-800-255-3924.
International Calls 1-813-248-0585

See the S.D.S. for more information

Distributed in Australia and New Zealand by:

Supercool Asia Pacific Pty Ltd,
ABN: 71 011 044 385,
14 Motorway Circuit, Ormeau,
QLD, 4208, Australia

Ph: (07) 5549 4000. Fax: (07) 5549 4004.
www.supercool.com.au
Emergency Ph: (07) 5549 4000